




- 1) Connect to the WiFi.
- 2) Go to the web browser and type 192.168.0.1, press Enter.
- 3) You should see this page:



- 4) Login using the password: **Freshtel2963**
- 5) You will see this page after login:



6) On the left hand side, go to **Wireless**.



7) And you will see your current WiFi name and password:

Wireless Settings

2.4GHz Wireless Network:

☒ Enable [Save Wi-Fi information](#)

Network Name (SSID):

TP-Link_F549

☐ Hide SSID

Password:

fVL7Hv2X

Low Middle High

Save

5GHz Wireless Network:

☒ Enable [Save Wi-Fi information](#)

Network Name (SSID):

TP-Link_F549_5G

☐ Hide SSID

Password:

fVL7Hv2X

Low Middle High

Save

8) First one is 2.4G, the second one is 5G.

9) You can now change the name and password following your requirement.

10) Click **Save** after the changes.